







Automatic Screw Machine User Manual

Shenzhen HengKong Technology Co.,Ltd

Tel: 0755-27726892 Fax: 0755-23017249

Catalog

Chapter 1 Overview	- 1 -
1.1 Hardware.....	- 1 -
1.2 Software	- 2 -
1.3 Accessory	- 3 -
1.4 Main board floor mounting dimensions(Height : 42mm)	- 5 -
1.5 Interface Schematic.....	- 6 -
1.6 Programmable input and output interface description.....	- 7 -
1.7 Button and LED interface description.....	- 8 -
1.8 Motor axis signal interface description	- 9 -
1.9 Limit signal and home signal interface description.....	- 9 -
Chapter 2 Main interface and key description	- 10 -
2.1 Main interface description.....	- 10 -
2.2 Teach box key description.....	- 11 -
2.3 Program selection and adjustment key description	- 14 -
Chapter 3 Shortcut menu description	- 15 -
3.1  Set the follow parameters of screw working	- 15 -
3.2  Set the delay time parameters.....	- 15 -
3.3  Set the parameters of screwdriver	- 15 -
3.4  Set the feeder parameters	- 16 -
3.5  Set the move speed.....	- 16 -
3.6  Set safety height parameter	- 16 -
Chapter 4 Menu 1.....	- 17 -
4.1 Page 1 1.File's name edit.....	- 17 -
4.2 Page 1 2.Default parameters.....	- 17 -
4.3 Page 1 3.Multiple programming.....	- 18 -
4.4 Page 1 4. Label set	- 18 -
4.5 Page 1 5. Array	- 19 -
4.6 Page 1 6. Array expand	- 19 -
4.7 Page 1 7. Call subroutine.....	- 19 -
4.8 Page 1 8. Call file	- 19 -

4.9	Page 1	9. Program jump	- 20 -
4.10	Page 2	1. Limited loop	- 20 -
4.11	Page 2	2. Program end.....	- 20 -
4.12	Page 2	3. Delay	- 20 -
4.13	Page 2	4. Pause.....	- 20 -
4.14	Page 2	5. Input program	- 20 -
4.15	Page 2	6. Output program	- 20 -
4.16	Page 2	7. Counter	- 21 -
4.17	Page 2	8. Go to the Location '0'	- 21 -
4.18	Page 2	9. Home	- 21 -
4.19	Page 3	1. Select feeder 1	- 21 -
4.20	Page 3	2. select feeder 2	- 21 -
Chapter 5 Menu 2.....			- 22 -
5.1	Page 1	1. Calibration set.....	- 22 -
5.2	Page 1	2. Calibration	- 22 -
5.3	Page 1	3. Limited Value of Z.....	- 22 -
5.4	Page 1	4. Output when emergency	- 23 -
5.5	Page 1	5. Output initialization.....	- 23 -
5.6	Page 1	6. Counter set.....	- 23 -
5.7	Page 1	7. Processing result view	- 23 -
5.8	Page 1	8. Get out's Location	- 23 -
5.9	Page 1	9. Stop set	- 23 -
5.10	Page 2	1. Delay set	- 24 -
5.11	Page 2	2. Screw driver limited	- 24 -
5.12	Page 2	3. Every times go home	- 24 -
5.13	Page 2	4. Auto calibration set.....	- 25 -
5.14	Page 2	5. Auto calibration	- 25 -
5.20	Page 2	6. Test getting screw	- 25 -
5.21	Page 2	7. Vacuum check set	- 25 -
Chapter 6 Menu 3.....			- 26 -
6.1	Page 1	1. Move to specified record	- 26 -
6.2	Page 1	2. Product file copy.....	- 26 -
6.3	Page 1	3. DXF file convert.....	- 27 -
6.4	Page 1	4. File locked	- 27 -
6.5	Page 1	5. Machine locked	- 27 -

6.6	Page 1	6. Menu 4 locked	- 27 -
6.7	Page 1	7. File password set	- 28 -
6.8	Page 1	8. Machine password set.....	- 28 -
6.9	Page 1	9. Menu 4 password set	- 28 -
6.10	Page 2	1. Input name edit	- 28 -
6.11	Page 2	2. Output name edit	- 28 -
6.12	Page 2	3. Buzzer of key.....	- 28 -
6.13	Page 2	4. Small key locked	- 28 -
6.14	Page 2	5. File view and edit	- 28 -
6.15	Page 2	6. Machine's information.....	- 28 -
6.16	Page 2	7. Program edition	- 29 -
6.17	Page 2	8.Program update.....	- 29 -
6.18	Page 2	9. FPGA update	- 29 -
6.19	Page 3	1. DSP update	- 30 -
6.20	Page 3	2. Input view	- 30 -
6.21	Page 3	3. Run from current record	- 30 -
6.22	Page 3	4. Button status view	- 31 -
6.23	Page 3	5. Output view and control	- 31 -
Chapter 7 Menu 4.....			- 32 -
7.1	Page 1	1-3. Set parameters of XYZ axis	- 32 -
7.2	Page 1	4. Password set	- 33 -
7.3	Page 1	5. Data/time set.....	- 33 -
7.4	Page 1	6. Limited used time	- 33 -
7.5	Page 1	7. Machine's name edit.....	- 33 -
7.6	Page 1	8. Company's name edit	- 33 -
7.7	Page 1	9. Start/Stop speed.....	- 33 -
7.8	Page 2	1. Acceleration set	- 34 -
7.9	Page 2	2.Maximum speed set.....	- 34 -
7.10	Page 2	3.Home's speed set	- 34 -
7.11	Page 2	4. Speed by manual.....	- 35 -
7.12	Page 2	5. Pinyin method update	- 35 -
7.13	Page 2	6. Boot screen update	- 35 -
7.14	Page 2	7. Program select mode	- 35 -
7.15	Page 2	8. System parameters copy	- 35 -
7.16	Page 2	9. Emergency mode	- 36 -

7.17	Page 3	1. Home way when boot.....	- 36 -
7.18	Page 3	2. Input/output set 1	- 36 -
7.19	Page 3	3. Input/output set 2.....	- 37 -
7.20	Page 3	4. Input/output set 3	- 38 -
7.21	Page 3	5.Clamp cylinder port.....	- 38 -
7.22	Page 3	6. Product check port.....	- 38 -
7.23	Page 3	7. Clamp cylinder expand.....	- 39 -
7.24	Page 3	8.Product check expand.....	- 39 -
7.25	Page 3	9. Feeder number	- 39 -
7.26	Page 4	1. Protect sensor set.....	- 40 -
7.27	Page 4	2. Number of Y axis.....	- 40 -
7.28	Page 4	3. Indicator port	- 40 -
7.29	Page 4	4. Run mode when double Y	- 41 -
7.30	Page 4	5. Red and green lights	- 41 -
7.31	Page 4	6. Get out cylinder port.....	- 41 -
7.32	Page 4	7. Get out cylinder time	- 42 -
7.33	Page 4	8. Get out cylinder check.....	- 42 -
7.34	Page 4	9. Servo or step	- 43 -
7.35	Page 5	1. Separate screw port.....	- 43 -
7.36	Page 5	2. Extra buzzer port	- 43 -
7.37	Page 5	3. X,Y moving mode	- 43 -
7.38	Page 5	4. Auto check port set	- 44 -
7.39	Page 5	5. Initialization.....	- 44 -
7.40	Page 5	6. Chinese-English shift.....	- 44 -
Appendix 1			- 45 -
		Method for setting the use time limit	- 45 -

Chapter 1 Overview

There are 3-5 controlling axis in the Automatic Screw Machine control system, which can support for automatic locking screw control of gantry structure with two worktables. The teach box of the machine adopt the 5 inch true-color LCD screen to make the operation menu and boot screen more abundant. To make the transmission speed faster and signal Anti-Interference, it adopts the Industrial field bus for connecting between main board and teach box. The teach box can not only storage processing file, system configure file, but also copying file each other when using multiple machines (or using the U Disk to copy). The Automatic Screw Machine control system using ARM + DSP + FPGA control program, with a strong computing power, short refresh time, excellent acceleration and deceleration performance in motion control, it can support high-speed high-precision 3D-line, three-dimensional circular motion. Its motion control board has 256M of storage space, can store 1000 processing files, each file can store 4000 programmed point, it can support work without teach box connection, processing files available digital number display and button Options to select.

1.1 Hardware

1. Motor axis number: 3-5 axis output.
2. Acceleration and deceleration performance: S-curve acceleration and deceleration mode, acceleration and deceleration acceleration set independently; 10K speed refresh rate, make the mechanical response better performance, less noise.
3. Pulse output frequency: 4MHz linear interpolation, 2MHz circular interpolation(including 3 axis space circular interpolation), Using a motor which has 20000 pulses each turn as an example, sufficient to meet the existing high-speed servo motor 5000 rpm/min requirements.
4. Home, Limit Input: Each motor has its own home-input, positive and negative limit-input, no need to take up the general input of programmable hardware resources.
5. Programmable input/output: it has 6 ways independent and dedicated programmable input and output, all used optical isolation and each output current up to 500mA.
6. Supporting 3 bits digital number tube interface, can change and switch 1000 files range 0-999 quickly.
7. Using the small key to adjust, in the absence of a teach box can also facilitate the realization of the error due to the changing an electric screwdriver head correction.
8. Owning CAN bus, RS-232, Ethernet, can be customized to the special needs of special programs
9. Read/Write in U Disk: Use the FAT32 file system, no longer than 2G capacity U disk can't be formatted to limit the FAT format.

10. Storage space: main board 256MB, can store 1000 processing files, each with 4000 program points; teach box 16MB, can store the boot screen, file, copy the file to each other in multiple machines is especially useful.
11. Screen of teach box: Use 480 X 272 pixels, 16 million true color 5-inch LCD screen, allowing the operator menu interface and boot screen is much more abundant.
12. Work Voltage: DC 24V, current 2A.
13. Work environment: degree 0°C--45°C, humidity 40%--80%.
14. Storage environment: degree -40°C--60°C, humidity 0%--95%.

1.2 Software


1. Three-dimensional linear interpolation, circular interpolation space (real hardware three-dimensional instead of line fitting).
2. Programming point of the editor can be 30 times the "undo" "redo", to prevent misuse effectively.
3. Machining parameter setting is set up in the programming point, which can be realized in the same process when different areas have different parameters.
4. In the return to the origin of the action when the axis back to the origin of the XYZ three axis at the same time the origin of the capture action.
5. With Quanpin IME to input Chinese.

1.3 Accessory

1. Main board



HK-3D-F00 Main board (194mm * 110mm * 42mm)



4D2Y Main board (224mm * 130mm * 42mm)

2. Teach box(242mm * 142mm * 26mm)




3. Program group selection and calibration panel (107mm * 40mm), Circuit board (70mm * 40mm)




4. Connecting line (Length can be customized)



1.4 Main board floor mounting dimensions(Height : 42mm)




HK-3D-F00 Main board




4D2Y Main board

1.5 Interface Schematic




HK-3D-F00 Interface Schematic




4D2Y Interface Schematic

1.6 Programmable input and output interface description



HK-3D-F00 programmable input and output interface




4D2Y programmable input and output interface

Note: 1. output n should not be short circuited with 24V, which will burn out chips.

2. N is the corresponding port, and the actual port is matched with the port in the parameter setting

1.7 Button and LED interface description



Note : 1. Enable drive indicator LED, connected to the positive terminal (+ 5V), common negative pole.

2. For Buttons, Connect one pin to the button signal, and the other to the common(0V).

Y1 Start, Y2 Start: Dual boot mode, start Y1 and Y2 workpiece respectively, can enter the running state without the run key.

Emergency: When the machine is out of control, or want to immediately stop the machine when running, press the emergency key, can occur an emergency alarm.

Back to the origin: the machine back to the origin after the reset operation.


Run/Pause: Press the operation, the machine into automatic operation, press again, machine in operation switching run state and the suspended state

Stop: Stop the machine running.

Step: After homing is completed within 10s of the press, automatic needle. After homing is completed 10s, control of the work piece clamping cylinders release and engage.

Screwdriver: Start the screwdriver and suction at the same time.

1.8 Motor axis signal interface description



4D2Y Motor axis signal

Note: The stepper driver can only be connected to 1, 2, 3, 4 pin; servo drive please refer to the servo instructions access feedback signal.

1.9 Limit signal and home signal interface description



HK-3D-F00 Home signal




4D2Y Limit signal and home signal

Chapter 2 Main interface and key description


2.1 Main interface description

1. Main interface description of content distribution.









































1. **888 : Prog888** File No. And File name, “001” is No., “程序 001” is file name.
2. **Modification time : 2015-06-03** Latest modified time of the file.
3. Icon of open processing file, can use “Table” key move the cursor to this icon.
4. “undo” “redo” state indication icon, up to 30 times to “undo”, “redo”, but can’t use when icon is gray.
5. Means the processing file is edited, need “debug” operation, when already debugged, the icon becomes gray.
6. File is not locked, file is locked, machine is locked.
7. **Speed:F** Move speed by manual, part of “fast, middle, slow”, press the "speed" key to switch.
8. **Count : 0/0** Workpiece counter, in front of the value is the count value of the workpiece, behind the value set the number of workpieces to be processed. If the work count reach the number of set to be processed, it will prompt that the workpiece counter is full.
9. Insert U Disk, No U Disk.
10. Pinyin input, number input, lower-case letter input, capital letter input, Press “#” can change the IME when in the character input state.

2.2 Teach box key description
















1. Z axis up by manual
2. Z axis down by manual
3. Y axis front by manual
4. Y axis back by manual
5. X axis left by manual
6. X axis right by manual
7. Switch to Y1 axis
8. Switch to Y2 axis
9. Switch manual speed “slow, middle, fast”.
10. Operation of exiting the menu or canceling the input dialog
11. Cursor switch between “machining programming point” area and “short menu bar” area, or transform plane when previewing.

12.  Analysis of the current file whether its programmed point accord with the programming rules, if yes, then the icon will become gray.
13.  Press this key can pop up some help information of the current page, press any key to exit
14.  Preview the screw holes graphic in current machining program file in XY, XZ, YZ plane position, press  to change plane, press other any key to exit. When screwdriver in limit using, press “preview” can clean the count of the current screwdriver.
15.   Undo and redo to the edition of programming points, up to 30 times, for preventing misuse effectively.
16.  In front of the cursor point of the selected insert a blank program point
17.  Delete the programming point of selected in main page, or in the menu state use for “delete” key.
18.  Jump to the special programming point address by manual input.
19.  Into Menu 1, for the point of action, displaying as black.
20.  Into Menu 2, for point of parameters setting, displaying as red.
21.  Into Menu3, for device of parameters setting and some application operation
22.  Perform to home.
23.  Perform step test.
24.  Work run or pause.
25.  Work stop.
26.  Cursor up a page in main page state, or up a page in menu state.
27.  Cursor down a page in main page state, or down a page in menu state.
28.  Cursor up a line in main page state, or up a line in menu state, or up a line in input dialog.
29.  Cursor down a line in main page state, or down a line in menu state, or down a line in input dialog.
30.  Screw hole program in main page, or input ‘1’, characters in input dialog.

31.  Set feeder position in main page, or input '2', 'abc' in input dialog.
32.  Set the speed and length of the screw parameters in main page , or input '3', 'def' in input dialog.
33.  Set the time parameters of screw controlling, or input '4', 'ghi' in input dialog.
34.  Set the parameters of the screwdriver in main page, or input '5', 'jkl' in input dialog.
35.  Set array of screw point in main page, or input '6', 'mno' in input dialog.
36.  Set move speed of XYZ axis when working in main page, or input '7', 'pqrs' in input dialog.
37.  Set safe height of Z axis when working in main page, or input '8', 'tuv' in input dialog
38.  Input '9', 'wxyz' in input dialog.
39.  Input '0' in input dialog.
40.  Input blank or decimal point in input dialog.
41.  Move to the programming point of cursor selected in main page, or switch IME or input negative value symbol in input dialog.
42.  +  Change Y axis between Y1 and Y2 then display when in double Y mode.
43.  +  Into menu 4, for bottom layer parameters of the device, suggested not open to users.
44.  +  Into menu 5, for system default parameters, set the initial value of the menu one
“Generate the default parameters”.

2.3 Program selection and adjustment key description



1.  The current file selected is file 123.
2.  Move the decimal point bit of the current file No., there is '+' '-' operation follow with the decimal point bit.
3.  Plus 1 on the bit of decimal point in the File No.
4.  Minus 1 on the bit of decimal point in the File No.
5.  Z axis move up by manual when adjusting.
6.  Z axis move down by manual when adjusting.
7.  Y axis move front by manual when adjusting.
8.  Y axis move back by manual when adjusting.
9.  X axis move left by manual when adjusting.
10.  X axis move right by manual when adjusting.
11.  Enter or confirm the adjustment operation, when enter the adjustment to the screw hole position, LED on the back of the film began flashing, press manual key then press confirm key to finish the operation. When the current cursor on the screw hole, then change the coordinate value by manual. When the current cursor on the parameter of point, then edit the parameters by manual.
12.  Cancel the adjustment operation.

Chapter 3 Shortcut menu description

3.1 Set the follow parameters of screw working

Driver speed: Means after go to a screw hole, turn on the screwdriver and begin to screw, the speed of Z axis followed down with the screw.

Driver length: Means after go to a screw hole, turn on the screwdriver and begin to screw, the length of Z axis followed down with the screw, generally set a slightly longer than the length of the screw.

3.2 Set the delay time parameters

Driver keep: 1. Torque mode: At this point, the power of the torque signal is turned on, and the screwdriver is worked by the follow-up length. If check no torque signal when the length is over, then the working screw delay is start, check the torque signal within the delay time, if no torque signal neither, display warning “screw loose”. 2. Time mode: At this point, the power of the torque signal is turned off, working screw delay is start and the screwdriver is worked by the follow-up length, when the time is over, then turn off the screwdriver signal, keep going until the length finish. When the length finish, waiting for the working screw delay is over, then the screw work finish.

Get delay: Time for delaying after turn on the vacuum valve when going to the feeder to get a screw, to ensure the stability of screw.

Finish delay: Delay when screw finish, mainly to allow the screwdriver own a stable time to put it up, can also set to ‘0’.

Floating time: Set ‘0’ to turn off floating alarm. In torque mode, when checked the torque, if screw time less than floating lock time, then alarm “floating lock”. There will display the screw time in the main page, to set the floating lock time conveniently.

3.3 Set the parameters of screwdriver

Finish signal “ON”, “OFF”: 1.set to “ON”, then worked in torque mode, refer to “working screw delay”. 2.set to “OFF”, then worked in time mode, refer to “working screw delay”.

Alarm “ON”, “OFF”: 1.set to “ON”, alarm “screw loose”, “floating lock” warning. 2. Set to “OFF”, ignore alarm.

3.4 Set the feeder parameters

Feeder signal “ON”, “OFF”: 1.set to “ON”, then every time when feeding will check the feeding signal, if yes, go to feed, and the signal will disappear. If signal is not disappear, means the screw is not taken, then take it again, until get a screw. 2. Set to “OFF”, go directly to the material, not feeding signal detection.

3.5 Set the move speed

Move speed of each axis at work. Reference value: 600-1000 (mm/s).

3.6 Set safety height parameter

Safety height: Z axis height above the screw hole when go to or left the screw hole. To prevent the collision between the screwdriver and work piece on the product.

Get height: the safety height when take the screw above the feeder, usually set slightly larger than the nut.


Leave height: the safety height after take a screw in the feeder, usually set slightly larger than the length of screw.

Chapter 4 Menu 1

Menu 1 is programming action and frequently-used file operation, Menu 1 generated by the programming point is usually the type of operation, with a black display. Menu 1 contains:

Menu1 Pg 1/3	Menu1 Pg 2/3	Menu1 Pg 3/3
1.File's name edit	1.Limited loop	1.Select feed 1
2.Default parameters	2.Program end	2.Select feed 2
3.Multiple programming	3.Delay	
4.Label set	4.Pause	
5.Array	5.Input program	
6.Array expand	6.Output program	
7.Call subroutine	7.Counter	
8.Call file	8.Goto the Location '0'	
9.Program goto	9.Home	

4.1 Page 1 1.File's name edit

Name the current processing file, press  to switch IME, and display the IME type on the upper right corner of the screen.


4.2 Page 1 2.Default parameters

Generate the default parameters before the file: 1.Follow-up parameters: follow-up speed and length; 2.Time parameters: work screw delay, feed screw delay, finish delay, floating lock time; 3.screwdriver parameters: torque check “ON”, “OFF”, alarm “ON”, “OFF”; 4. Feeder parameters: material check “ON”, “OFF”; 5.Move speed: move speed of XYZ axis; 6.Safety height : Safety height above the screw hole, Screw feeder safety height, Feeder left safety height. The value of default parameters can be set in Menu 5(stop + menu2).

```
0001 screwdriver parameter : 30(mm/s) length : 12(mm)
0002 time(s) screwdriver:1.500 feed:0.100 finish:0.030 float:0.000
0003 finish signal : OFF alarm : OFF
0004 feed signal : OFF
0005 Move speed X : 600.000 Y : 600.000 Z : 600.000
0006 safety height : 18.000 get height : 8.000 leave height : 10.000
```

4.3 Page 1 3. Multiple programming

1. **Copy:** Copy the programming point in the edit range to the specified programming point address.
2. **Delete:** delete the programming point in the edit range.
3. **Move:** move the programming point in the edit range to the specified programming point address. This function mainly used for adjusting the process order of all screws.
4. **Offset:** Offset the coordinate of the programming point in the edit range.
5. **Z value:** set the Z axis value of the programming point to the same in the edit range.
6. **Plane rotation:** Rotating the programming point in the edit range, mainly used for correcting when the clamp tool is rotated without programming again.
7. **Zoom:** Zoom the graphic of programming point in or out in the edit range, mainly used for correcting when DXF file generating processing file due to the accuracy of the machine caused the deviation by the processing size and the actual size.
8. **Teach offset:** Generally used in the CAD map, the CAD on a point and the corresponding point on the work table to teach offset. The coordinates of the hole of the screw hole in the edit range are carried out accordingly.
9. **Y exchange:** Switch the Y axis of the screw hole to another in edit range.




4.4 Page 1 4. Label set

Labels can not only used to called with array, loop, sub, jump, general input programming, etc. but also be used to program comments to improve the readability of the program.

4.5 Page 1 5. Array

If processing fixture plate placed multiple horizontal and vertical arrangement of the work piece, and horizontal and vertical respectively spacing is consistent then can use array, as long as the series good machining of one work piece, and then use the array can achieve full disk work piece machining, so that programming efficiency is greatly improved.



If the fixture plane with the XY plane is consistent with the plane, and horizontal and vertical with the X, Y axis parallel to the direction then can use the first array, also the second ways. If the fixture plane is not consistent with the XY plane, or horizontal, vertical and X, Y axis direction is not parallel to the direction, then can only use the second array methods.

Array -- Method 1	Array -- Method 2
Orientation: 1.Horizontal 2.Vertical Select: <u>1</u>	Orientation: 1.Horizontal 2.Vertical Select: <u>1</u>
Column: <u>5</u>	Column: <u>5</u>
Row: <u>4</u>	Row: <u>4</u>
Offset X(mm): <u>10.000</u>	Horizontal location: 247.999 10.043 0.000
Offset Y(mm): <u>10.000</u>	Vertical location: 10.010 208.618 0.000
Array call: 1.Address 2.Label Select: <u>1</u>	Array call: 1.Address 2.Label Select: <u>1</u>
Address: <u>0008</u>	Address: <u>0008</u>

4.6 Page 1 6. Array expand

Selected the array programming point of the cursor in the main page, performing array deployment can generate programming points with the same effect as the array. It can modify each screw hole when the tool disc is not regular.

4.7 Page 1 7. Call subroutine

If processing fixture plate placed multiple direction, but there is no rule of the work piece. It is only necessary to programming and machining of one work piece then call the subroutine in each part of the first screw position. It can call the address or the label of the subroutine.

4.8 Page 1 8. Call file

The way to call file is the same to call subroutine, as long as change the called subroutine to a file No., and change the processing programming point from the subroutine to the file.

4.9 Page 1 9. Program jump

Program jump to special address or label to run when run to the current programming point, usually used to loop.

4.10 Page 2 1. Limited loop

It is similar to the “program jump”, just the “program jump” is no limit counts when loop.

4.11 Page 2 2.Program end

When in a subroutine execution to the programming, the subroutine returns, when not in a subroutine execution to the programming is processing the end of the program. If there are more than two lines of “no programming point” means the end of the program.

4.12 Page 2 3. Delay

If the program execution to the delay programming point is processed to stop the time delay a certain period of time and then continue to execute the processing point.

4.13 Page 2 4. Pause

If the program execution to the pause programming point, waiting for the run key then continue to execute the processing point. It achieves the “run key to loop”. When programming, add pause after the programming point of Y1, add pause after the programming point of Y2, then add jump instruction.

4.14 Page 2 5. Input program

Programming input signal is when the program execution to the programming of the point, if the values of the input state accord with the specified input signals then program jump to the specified address or label, if not then program continue to execute. Use this function can be achieved with other devices with the work or as a pause key input, etc. (Signal definition: if has the input signal then the signal is defined as the amount of 1, no input signal is defined as the amount of the signal 0).

4.15 Page 2 6. Output program

When the program is executed to the output signal programming point, then the output signal will output specified value, 1 as DC24V output, 0 as DC0V output. When debugging, we can testing the corresponding output, such as starting the screwdriver, controlling solenoid valve suction, clamping cylinder, etc.

4.16 Page 2 7. Counter

When the program is executed, the work piece counter increases the corresponding set value and then compares the value of the counting value to overflow limit, if overflow then stopped, This function usually used to count loop work pieces.

4.17 Page 2 8. Go to the Location '0'

When execute this command, then the XYZ axis will go back to '0' position as empty move speed, without the action of searching the origin.

4.18 Page 2 9. Home

This current programming point makes the machine back to the origin.

4.19 Page 3 1. Select feeder 1

Select feeder 1 when set “set feeder number” as 2 in menu 4.

4.20 Page 3 2.select feeder 2

Select feeder 2 when set “set feeder number” as 2 in menu 4.

Chapter 5 Menu 2

Menu 2 is mainly for the parameter settings of the programming point, Menu 2 generated by the programming point is usually display black. Menu 2 contains:

Menu2	Pg 1/2	Menu2	Pg 2/2
1.Calibration set		1.Delay set	
2.Calibration		2.Screw driver limited	
3.Limited Value of Z		3.Every times go home	
4.Output when emergency		4.Auto calibration set	
5.Output initialization		5.Auto calibration	
6.Counter set		6.Test getting screw	
7.Processing result view		7.Vacuum check set	
8.Get out's Location			
9.Stop set			

5.1 Page 1 1.Calibration set

Adjustment point, when there is some processing offset caused by the deviation of screwdriver or fixture, we can use the adjustment point to correct it. There are two ways to set the adjustment point, one is take the first screw hole's coordinate as the adjustment point, the other is set the coordinate by manual, if choose the second one, move the screwdriver to the specified position, then press confirm.

5.2 Page 1 2. Calibration

When into the calibration menu , the screwdriver move to the adjustment point automatically, then move the screwdriver to the specified coordinate to calibrate, pressing confirm to finish this calibration operation. Then all the processing point will compensate the deviation from the offset of screwdriver to ensure machining accuracy unchanged.

This function can also use the special calibration on the keyboard to operate while no teaching box available, as long as the machine in an idle state, we can press “confirm” key into the calibration operation, at the same time the keyboard mask on the LED will flash, then move the screwdriver to the specified coordinate by manual, press “confirm” again to complete the calibration of the operation, then the LED will extinguish and exit.

5.3 Page 1 3.Limited Value of Z

Set this value to limit Z axis down to prevent the screwdriver down to the number of collision work piece or the tool by manual, each processing file has its own Z axis value.

5.4 Page 1 4. Output when emergency

Set the general output signal when emergency occurrence, '1' means 24V, '0' means 0V.

5.5 Page 1 5. Output initialization

Set the general output signal when turn on the machine, '1' means 24V, '0' means 0V.

5.6 Page 1 6. Counter set


We can set the count value and limit count value in the work piece counter, as running, the count value will add the set number when execute to the programming point, if the count value larger than the count limit value, prompt that count overflow, and stop processing, until set the count again. If not use the work piece count limit, please set the count limit value as 0.

5.7 Page 1 7. Processing result view

View production status, number of completed screws, qualified rate of screw hole, number of completed products, qualified rate of product.

Screw qualified rate = number of screw finished / number of all screws.

Product qualified rate = number of product finished / number of all products.



5.8 Page 1 8. Get out's Location

When the product process finished, then get out the position of product.

Front of the workbench: set Y axis end as the get product position;

Behind the workbench: set Y axis start as the get product position.

5.9 Page 1 9. Stop set

When press the stop in product processing,

Keep: next time start, continue to process at the stop position last time;

Clear: next time start, process at the first screw hole.

5.10 Page 2 1.Delay set

product and cylinder delay

Delay after detecting product(s): 0.000

Delay after getting out product(s): 0.000

Delay after clamp cylinder Y1 works(s) : 0.000

Delay after clamp cylinder Y2 works(s) : 0.000

Delay after detecting product(s): after check the product, delay a period of time, then perform next action.

Delay after getting out product(s): perform the next action after the product removed at the location of product and delay a period of time.

Delay after clamp cylinder Y1 works(s): After driving Y1 axis clamping the work piece cylinder solenoid valve and delay a period of time, then perform the next action.

Delay after clamp cylinder Y2 works(s): After driving Y2 axis clamping the work piece cylinder solenoid valve and delay a period of time, then perform the next action.

5.11 Page 2 2. Screw driver limited

screwdriver usage limitation

limited(times): 0

times been used: 0

Press 'Preview' clear the data!

Set the limit count of screwdriver, each finish a screw, the number of screw driver using count will add 1, when the using count reach the number of limit count, then prompt changing the head of screwdriver. If no limit count, set the limit count as 0.

5.12 Page 2 3.Every times go home

Home after how many times


Home after how many times: 0

count type 1.screw 2.product select: 1

Count type: 1. Screw, if the number of processing reach to the number of screw hole ever been set, go back to the origin, then continue.

2. Product if the number of processing reach to the number of product ever been set, go back to the origin, if in the loop mode, then continue.

5.13 Page 2 4. Auto calibration set



Move the screwdriver to the center of automatic check sensor, with a moderate height. After press the “confirm”, the screwdriver will search the XYZ axis sensor trigger point from all directions, then get the coordinate of the screwdriver check point.

5.14 Page 2 5.Auto calibration

Check the adjustment point automatically, move the screwdriver to the last adjustment point, then search the XYZ axis sensor trigger point from all directions, to get the new adjustment point. By comparing the last and the new coordinates of the adjustment point, generating the coordinate offset of XYZ axis. Then all the screw hole’s coordinates move a distance according to the offset to get the new coordinate of programming point.

5.20 Page 2 6. Test getting screw

Test getting screw, turn on suction, screwdriver, go to the position of feeder, stop at the top of the feeder, press stop, then turn off the suction and screwdriver.

5.21 Page 2 7. Vacuum check set

Choose whether to open the vacuum detection.

Chapter 6 Menu 3

Menu 3 is mainly machine setting or menu operation, no programming point generated. Menu 3 contains:

Menu3 Pg 1/3	Menu3 Pg 2/3	Menu3 Pg 3/3
1.Move to specified record	1.Input name edit	1.DSP update
2.Product file copy	2.Output name edit	2.Input view
3.DXF file convert	3.Buzzer of key	3.Run from current record
4.File locked	4.Smallkey locked	4.Button status view
5.Machine locked	5.File view and edit	5.Output view and control
6.Menu 4 locked	6.Machine's information	
7.File password set	7.Program edition	
8.Machine password set	8.Program update	
9.Menu 4 password set	9.FPGA update	

6.1 Page 1 1.Move to specified record

When input the specific coordinate and press “confirm” key after enter the menu, the machine will move to the coordinate just inputted.

6.2 Page 1 2. Product file copy

This function can storage in U Disk or teach box and copy files between each machine, when there are several machines process the same file, we can just program in one screw machine and copy it to others. The teach box copying applies to the field using, and the U Disk copying can not only between screw machines, but also storage in the computer as backup. File copying operation contains:

1. Form machine to teach box

This operation copy the current processing file to the teach box.

2. From machine to U Disk

This function reserve.

3. From teach box to screw machine


This operation copy the storage file in the teach box to replace the current processing file in the screw machine.

4. From U Disk to screw machine

This function reserve.

5. Copy between each machines

This operation copy files with different file No. to replace, mainly used to processing files backup.





6.3 Page 1 3. DXF file convert


Save the AutoCAD graphics file as AutoCAD 2010 DXF format file to “螺丝机\DXF 文件” folder, then operating this menu to convert graphics files into processing files.



6.4 Page 1 4.File locked

When the file unlock, icon display  in the status bar, meanwhile the parameters of current file and machine all can be modified; when the file lock, icon display  in the status bar, meanwhile the current file can't be modified , but not the parameters of the machine.

6.5 Page 1 5. Machine locked

When in unlock states, the parameters of machine can be modified, whether the file is locked is up to the file lock/unlock setting; when in lock states, icon display  in the status bar, meanwhile all the parameters of file and machine are locked.

6.6 Page 1 6. Menu 4 locked

When in unlock states, the content of menu 4 can be view or modify; but when in lock states, the function of menu 4 is forbidden.

6.7 Page 1 7. File password set

This menu is used to set the password for the “Page 1 4.lock/unlock for current file”

6.8 Page 1 8. Machine password set

This menu is used to set the password for the “Page 1 5. Advanced lock/unlock machine”

6.9 Page 1 9. Menu 4 password set

This menu is used to set the password for the “Page 1 6. Menu 4 lock/unlock machine”

6.10 Page 2 1. Input name edit

The default name of programmable universal input port is “通用输入 01”--“通用输入 12”, to improve the readability of the program, each programmable universal input port can be named according to the function of the application, so that the programming is more convenient.

6.11 Page 2 2. Output name edit

The default name of programmable universal output port is “通用输出 01”--“通用输出 12”, to improve the readability of the program, each programmable universal output port can be named according to the function of the application, so that the programming is more convenient.

6.12 Page 2 3. Buzzer of key

This menu can set whether the key voice of teach box is on or off.

6.13 Page 2 4. Small key locked

Small keyboard means special keyboard for the check adjustment point, this menu usually used to prevent misuse with locking this keyboard and taking the teach box away.

6.14 Page 2 5. File view and edit


Because the processing file is so many (1000 files), it's terrible to open and search file one by one, so we can use this function for tabbed browsing, find the number of file we wanted then open it, also can press “delete” key to delete the selected file.

6.15 Page 2 6. Machine's information

Display the device information, such as machine number, etc.


6.16 Page 2 7. Program edition


Display the program version information.




The picture shows the application program, version Year-month-day. Before the new version update, we will use it frequently to ensure the version of program of current device.

6.17 Page 2 8.Program update

As long as put the application program file into U Disk of FAT32 format with folder called “螺丝机/升级文件”, enter the menu and update the program after insert the U Disk. If the U Disk can identify correct, icon  will display at the right in status bar.




6.18 Page 2 9. FPGA update

As long as put the driver program file into U Disk of FAT32 format with folder called “螺丝机/升级文件”, enter the menu and update the program after insert the U Disk. If the U Disk can identify correct, icon  will display at the right in status bar.



6.19 Page 3 1. DSP update

As long as put the DSP program file into U Disk of FAT32 format with folder called “螺丝机/升级文件”, enter the menu and update the program after insert the U Disk. If the U Disk can identify correct, icon  will display at the right in status bar.



6.20 Page 3 2. Input view

As shown in the following picture:

output view

output:

b	01	02	03	04	05	06	07	08	09	10	11	12
v	0	0	0	0	0	0	0	0	0	0	0	0

Origin/limited

b	S1	S2	S3	S4	S5	H1	H2	H3	H4	H5	E1	E2	E3	E4	E4
v	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

0-12 of “general input” is 12 input states for programmable input port, when check input signal for ‘1’, no input signal for ‘0’.

“origin limit” is input state of origin signal and limit signal, S1-S5 for 1-5 axis negative direction limit signal, H1-H5 for 1-5 axis origin signal, E1-E5 for positive limit signal, when check input signal for ‘1’, no input signal for ‘0’.

6.21 Page 3 3. Run from current record

This function usually used to work the leftover screw at the specified screw hole when there are some little errors in the process midway.

6.22 Page 3 4. Button status view

Button status view

Origin:0 Run:0 Stop:0 Step:0 screw:0 Y1 Start:0 Y2 Start:0

View the input state of function key, when no key means states is 0, when check key down means states is 1.

6.23 Page 3 5. Output view and control

output view

output:

b	01	02	03	04	05	06	07	08	09	10	11	12
v	0	0	0	0	0	0	0	0	0	0	0	0

View general output state, also control the output state of general output port. Set 1 means open the corresponding port, set 0 means close the corresponding port.

Chapter 7 Menu 4

Press “Stop” + “Menu1” into Menu 4, Menu 4 is the menu for manufacturer to set parameters of machine, not recommend opening for users. Menu 4 contains:

Menu4 Pg 1/5	Menu4 Pg 2/5	Menu4 Pg 3/5
1.Axis X Parameter	1.Acc set	1.Home way when boot
2.Axis Y Parameter	2.Maximum speed set	2.input/output set 1
3.Axis Z Parameter	3.Home's speed set	3.input/output set 2
4.password set	4.Speed by manual	4.input/output set 3
5.data/time set	5.Pinyin method update	5.Clamp cylinder port
6.Limited used time	6.Boot screen update	6.Product check port
7.Machine's name edit	7.Program select mode	7.Clamp cylinder expand
8.Company's name edit	8.System parameters copy	8.Product check expand
9.Start/Stop speed	9.Emergency mode	9.Feeder number

Menu4 Pg 4/5	Menu4 Pg 5/5
1.Protect sensor set	1.Seperate screw port
2.Number of Y axis	2.Extra buzzer port
3.Indicator port	3.X,Y moving mode
4.Run mode when double Y	4.Auto check port
5.Red and green lights	5.Initialization
6.Get out cylinder port	6.Chinese-English shift
7.Get out cylinder time	
8.Get out cylinder check	
9.Servo or step	

7.1 Page 1 1-3. Set parameters of XYZ axis

The motor shaft parameter setting options are shown below:

Axis X parameter

Pulse/r: 6400

Screw pitch(mm): 52.000

Length(mm): 300.000

Offset at origin(mm): 0.000

origin: 1.Close 2.Open 3.No use select: 2

limited: 1.Close 2.Open 3.No use select: 3

Pulse/r: means the number of pulses for the driver motor per revolution, or the fine fraction of driver motor.

Screw pitch: means the run distance for the driver motor per revolution, or the circumference of the belt pulley or the pitch of lead screw.

Length: The longest distance the axis can move.

Offset at origin: Home offset can be 0 or others, as well as offset the error value as coordinate 0 after capture the home position.

Close/Open: Close if capture sensor output low voltage when motor shaft don't trigger the origin, and the opposite is open.

No use: If you select no use, the axis does not use the origin or limited.

7.2 Page 1 4. Password set

Before set the use limit time, set the password first.

7.3 Page 1 5. Data/time set

Set the date or time of the system.

7.4 Page 1 6. Limited used time

Prompt input 16 bit password. The format of password reference appendix 1. But set the password first before use this function.

7.5 Page 1 7. Machine's name edit

The name of device edited will display at "menu 3, page 2, 4 .device information".

7.6 Page 1 8. Company's name edit

The name of company edited will display at "menu 3, page 2, 4 .device information".

7.7 Page 1 9. Start/Stop speed

The motor has a process of acceleration and deceleration in motor control applications when running, to improve work efficiency, start/stop speed can set neither 0 nor too large, the greater the load, the smaller the start/stop speed, or it will cause the loss of step or mechanical noise, general recommendations in 20 mm/s.

7.8 Page 2 1. Acceleration set

Various acceleration contains:

ACC set(mm/(s*s))	
X start ACC:	<u>6000</u>
X stop ACC:	<u>6000.000</u>
Y start ACC:	<u>6000.000</u>
Y stop ACC:	<u>6000.000</u>
Z start ACC:	<u>6000.000</u>
Z stop ACC:	<u>6000.000</u>
start ACC by manual :	<u>400.000</u>
stop ACC by manual :	<u>400.000</u>

The manual move speed can set a little smaller in actual use, generally between 100-500, manual moving acceleration is set a little smaller to have an obvious start acceleration process in manual operation, it is easy to move a short distance when it is moving at a high speed, satisfied the speed and short distance requirements.

The control card support asymmetric acceleration and deceleration, start acceleration and stop acceleration can be set to different values, the actual application of the general will be set larger to stop the acceleration than the start acceleration. The acceleration of the size of the setting must be according to the motor drive capacity, load size, mechanical properties, etc. taking not lose step, shaking not big as the standard.

7.9 Page 2 2.Maximum speed set

Setting the maximum value allowed by each axis speed in user programming, this will prevent the user from setting a speed that is greater than the speed of the machine design requirements, so that prevent the lose of step.

7.10 Page 2 3.Home's speed set


Origin capture is record the position of motor shaft when it trigger the origin signal, in order to be in the same position every time, it must be triggered in the same direction every time, so we must move to the correct direction first then perform origin capture when the position of motor shaft is not at the direction of origin capture direction.

“move speed” is the speed that the motor shaft move from error direction to the direction of origin capture, this speed can be upper, generally set range as 50-150mm/s, “capture speed” is the speed that motor shaft move to trigger the origin signal, to improve the accuracy, this speed should not be too high, generally set range as 20-60mm/s.

Home's speed set(mm/s)	
Move speed(mm/s):	<u>80</u>
Capture speed(mm/s):	<u>30</u>

7.11 Page 2 4. Speed by manual

Manual movement speed is high, medium and low speed of three, press “speed” can cycle switch. Generally set high speed as 80mm/s, middle speed as 40mm/s, low speed as 1mm/s.



7.12 Page 2 5. Pinyin method update

Pinyin IME use the GB2312 library, almost 7000 commonly used Chinese characters, usually the factor has been updated the Pinyin IME, so it's no need to perform this action.

7.13 Page 2 6. Boot screen update

Make the required boot logo to a 480X272 pixels,24 bit color bitmap file with PhotoShop, then save it to the folder called “螺丝机/LOGO” of the U Disk, insert the U Disk and perform the update operation. (Note: The U Disk must be formatted as FAT32)

7.14 Page 2 7. Program select mode


We can use two ways to select the processing file, dial switch and digital tube, if using the dial switch, we can have 1 bit, 2 bit, 3 bit, and the high bit will default as 0 if not use. As well as there is no conflict between the opened file number and the value of the dial, the function which opening file of the teach box will be shield.

7.15 Page 2 8. System parameters copy

The function of this menu is copying the system parameters from one machine to teach box or U Disk and then copy it from teach box or U Disk to other same size machines, no need to set them one by one.


If save to the U Disk, must create the folder called “螺丝机-配置文件” first, and the suffix of this file must be “CFG”. (Note : U Disk must be formatted as FAT32)

The contents of the copy include the machine parameters and the default values of the factory settings.




7.16 Page 2 9. Emergency mode

When prompt “emergency” press “cancel” to enter the menu of set emergency mode, so we can modify it quickly if the emergency stop switch damaged or need to modify the emergency mode.



7.17 Page 3 1. Home way when boot

1. Prompt home when boot: prompt to go back to the origin when the machine power on, press “home” to perform this action.
2. Home when boot: go directly to the origin when the machine power on.
3. No prompt and no home when boot: must press “home” to perform this action after the machine power on.



7.18 Page 3 2. Input/output set 1

Screwdriver finish signal (input): A port of screwdriver stalling, corresponding to the actual wiring.

Type 1. ON 2 OFF: the type of stall signal.

Detect type 1. Capture 2. Scanning: the style of main board checking stall signal, capture, means to catch a rising edge or falling edge. Scanning, means to check a signal ON or OFF. Setting according to the type of stall output signal. If the stall signal is an instantaneous signal, then set to capture, if it is to maintain the signal, then set to scan. Some of the screwdriver will have a very short interfering signal, the use of scanning mode can filter out the interference signal.

Feeder 1 signal (input): feeder, the port of response the signal of screw, corresponding to the actual wiring.

type1. ON 2.OFF: the type of material feeding signal.

Screwdriver output (output): set the screwdriver control port, corresponding to the actual wiring.

Suction output (output): set the port of suction solenoid, corresponding to the actual wiring.

Suction delay (s): Starting from the screw working to start the time, after the setting time, the suction closed. If the setting time is larger than the screw process time, then screw finished and the suction is closed. If set as 0, then close the suction after screw finished.

Screwdriver Port 1

screwdriver finish signal(input): 0
 type 1.normal open 2.normal close select: 1
 detect type 1.capture 2.scan select: 1
 Feeder 1 signal(input): 0
 type 1.normal open 2.normal close select 1
 screwdriver output(output): 0
 suction output(output): 0
 suction delay(s): 0.000

7.19 Page 3 3. Input/output set 2

Up/Down cylinder signal (output): the port of down cylinder, when the cylinder is at the top of Z axis, corresponding to the actual wiring. If there is no cylinder, set as 0.

Vacuum check (input): set the port of screwdriver vacuum check, corresponding to the actual wiring. If not use, set as 0. When turn on the vacuum check, the screwdriver will check vacuum signal at the top of screw hole, if it is not normal, it will produce a vacuum alarm.

Type 1.ON 2. OFF: the type of vacuum signal.

Clear (Output): Set the port of clear, corresponding to the actual wiring. If not use, set as 0.

Screwdriver mode 1.always 2.stop: set as 1, then the screwdriver will turn on always, if set as 2 ,then the screwdriver only turn in at getting screw and working screw, but not moving the screwdriver.

Product detect 1. Pass 2.run request: set as 1, then the machine will work if check the product put OK signal, if set as 2, then after check the product put OK signal, press Run button to start.

Pin cylinder (Output): Set the port of pin cylinder, corresponding to the actual wiring. If not use, set as 0.

Feeder 2 signal (input): only when the number of feeder is 2, this menu will be showed. Feeder 2, the port of response the signal of screw, corresponding to the actual wiring.

Screwdriver Port 2

up/down cylinder(output): 0
 vacuum check(input): 0
 type 1.normal open 2.normal close select: 1
 clear(output): 0
 screwdriver mode 1.always 2.stop select 1
 Product detect 1.pass 2.run request select: 1
 pin cylinder(output): 0
 Feeder 2 signal(input): 0

7.20 Page 3 4. Input/output set 3

Screwdriver Port 3
after alarm 1.not home 2.home select: 1

After alarm 1. Don't go to home 2. Go to home: set as 1, then if check the warning of screw lock or loose, don't go to home, if set as 2, then go to home after check the warning.

7.21 Page 3 5.Clamp cylinder port

clamp cylinder port
Y1 clamp cylinder port: 0
Y1 clamp cylinder check port : 0
type 1.normal open 2.normal close select: 1
Y1 clamp cylinder out delay(s): 0.000
Y2 clamp cylinder port: 0
Y2 clamp cylinder check port : 0
type 1.normal open 2.normal close select: 1
Y2 clamp cylinder out delay(s): 0.000

Clamp cylinder port: output port of solenoid valve for driving and clamping cylinder of work piece, when set as 0, then the port function is shield.

Clamp cylinder check port: input port of checking the clamping cylinder, when set as 0, then the port function is shield. When the cylinder is clamped by the input signal, if not checked the input signal after clamp the cylinder, it will release the cylinder and clamp again, until check the input signal.

Signal type: Signal type of clamping cylinder in sensor.

Clamp cylinder out delay: Drive clamping work piece cylinder solenoid valve after a period of time delay and then perform the next action, can also be set as '0'.

7.22 Page 3 6. Product check port

product detect port
Y1 product detect port: 0
type 1.normal open 2.normal close select: 1
Y2 product detect port: 0
type 1.normal open 2.normal close select: 1
delay after detect product(s): 0.000
delay after get out(s): 0.000

Product detect port: input port of checking whether the product is OK, when set as 0, then the port function is shield.


Signal type: signal type of checking the work piece.

Delay after detect product: checked the product after a period of time delay and then perform the next action,

can also be set as '0'.

Delay after get out: processing finish and get out the product when check the signal after a period of time delay and then perform the next action, can also be set as '0'.

7.23 Page 3 7. Clamp cylinder expand




clamp cylinder expand port

Y1 clamp cylinder check 2 port: 0

Y2 clamp cylinder check 2 port: 0

Some occasions, there are two products in one workbench, and they all have the controlling of clamping cylinder with input signal check. Only the two cylinder clamp the product at the same time, then the product clamped OK and perform the next step. The two sensors are respectively corresponding to the clamping input port and the clamping input expansion port.

7.24 Page 3 8.Product check expand




product detect expand port

Y1 product detect 2 port: 0

Y2 product detect 2 port: 0

Some occasions, there are two products in one workbench, and they all have the sensor check. Only the two sensors capture the product at the same time, then the product put OK and perform the next step. The two sensors are respectively corresponding to the work piece checking port and the work piece checking expansion port.


7.25 Page 3 9. Feeder number



set feeder num

number of feeder: _____

We can set the number of feeder as one or two, when set as two, we can feed screw at the special feeder in the program point. This operation can not only meet the two kinds of the same size of the different length of the screw processing, but also be processed in the short path.


7.26 Page 4 1. Protect sensor set

Protect sensor set

Protect sensor port : 0

type 1.normal open 2.normal close select : 0


This function protects objects and people in the process of screw working. If the grating protect has induction, then it will stop running and alarming in the running or back to the origin state. In standby mode, there are grating protection, will prompt the grating sensor, but will not generate the alarm, at this time, the machine cannot be returned to the origin and operation until the grating sensor disappears.

7.27 Page 4 2. Number of Y axis

Number of Y

1.Single 2.Double

Set single/double Y axis, single Y as 1, double Y as 2.

7.28 Page 4 3. Indicator port

Indicator port set

Y1 front green light port: 0

Y1 front yellow light port : 0

Y1 back green light port: 0

Y1 back yellow light port: 0

Y2 front green light port: 0

Y2 front yellow light port : 0

Y2 back green light port: 1

Y2 back yellow light port: 0


Port setting of the before and after led.

Wait for feeding, front yellow led flashes. After the material OK, front green light. After the completion of the processing, if there is NG hole, then back yellow light, if the product is OK, then the green light both front and back.

7.29 Page 4 4. Run mode when double Y


Double start: press the total running key, put the product OK, press Y1 to start and Y1 clamping cylinder begin to work, when clamping finished, waiting for processing after the screwdriver is free. Press Y2 to start, and Y2 clamping cylinder begin to work, when clamping finished, waiting for processing after the screwdriver is free.

Product detect: press the total running key, put the product OK, Y1 work piece checking OK and Y1 clamping cylinder begin to work, when clamping finished, waiting for processing after the screwdriver is free. Y2 work piece checking OK and Y2 clamping cylinder begin to work, when clamping finished, waiting for processing after the screwdriver is free.




7.30 Page 4 5. Red and green lights

Set port of machine indicator led, when the machine works, the green light is bright, when the machine is screwing with alarm, the red light flashes, the green light goes out, and when the operation is run again, the green light is bright, and the red light is turned off. When stop, the lights all go out.



7.31 Page 4 6. Get out cylinder port



This function is mainly used for getting out the finished product automatically.

Y1 vertical cylinder: set the port of Y1 vertical cylinder, corresponding to the actual wiring.

Y1 suction cylinder: set the port of Y1 suction cylinder, corresponding to the actual wiring.

Y1 horizontal cylinder: set the port of Y1 horizontal cylinder, corresponding to the actual wiring.

Y2 vertical cylinder: set the port of Y2 vertical cylinder, corresponding to the actual wiring.

Y2 suction cylinder: set the port of Y2 suction cylinder, corresponding to the actual wiring.

Y2 horizontal cylinder: set the port of Y2 horizontal cylinder, corresponding to the actual wiring.

When the product processing finished , Y axis go to the position, vertical cylinder down, suction cylinder open, vertical cylinder up, horizontal cylinder push, suction cylinder release, product fall into the product line, horizontal cylinder retract.

7.32 Page 4 7. Get out cylinder time

Get out cylindre time	
Y1 vertical cylinder down time:	<u>2.000</u>
Y1 horizontal cylinder push time:	<u>2.000</u>
Y2 vertical cylinder down time:	<u>2.000</u>
Y2 horizontal cylinder push time:	<u>2.000</u>

Time for Y1 vertical cylinder down: time for Y1 vertical solenoid valve output.

Time for Y1 horizontal cylinder push: time for Y1 horizontal solenoid valve output.

Time for Y2 vertical cylinder down: time for Y2 vertical solenoid valve output.

Time for Y2 horizontal cylinder push: time for Y2 horizontal solenoid valve output.

7.33 Page 4 8. Get out cylinder check

Get out cylinder check	
Y1 vertical cylinder up check:	<u>0</u>
Y1 horizontal cylinder push check:	<u>0</u>
Y2 vertical cylinder up check:	<u>0</u>
Y2 horizontal cylinder push check:	<u>0</u>
Y1 suction cylinder check:	<u>0</u>
Y2 suction cylinder check:	<u>0</u>

Y1 vertical cylinder up check: set port for Y1 axis vertical cylinder up checking, corresponding to the actual wiring.

Y1 horizontal cylinder push check: set port for Y1 axis horizontal cylinder push checking, corresponding to the actual wiring.

Y2 vertical cylinder up check: set port for Y2 axis vertical cylinder up checking, corresponding to the actual wiring.

Y2 horizontal cylinder push check: set port for Y2 axis horizontal cylinder push checking, corresponding to the actual wiring.

Y1 suction cylinder check: set port for Y1 axis suction cylinder checking, corresponding to the actual wiring.

Y2 suction cylinder check: set port for Y2 axis suction cylinder checking, corresponding to the actual wiring.

7.34 Page 4 9. Servo or step

X axis 0.step 1.servo: set X axis as step or servo.

Y1 axis 0.step 1.servo: set Y1 axis as step or servo.

Z axis 0.step 1.servo: set Z axis as step or servo.


Y2 axis 0.step 1.servo: set Y2 axis as step or servo.

Servo 0.close 1.open: the total switch, when select 1, the above four settings are valid, otherwise closed, the above four is no effect. When select servo, it will check servo alarm, when back to the origin, it will output the clean signal of servo alarm. Connection reference the definition of motor shaft connection.

7.35 Page 5 1. Separate screw port


When the cylinder is separated from the screw, please set the port according to the connection. There are few customs using this feeding mode.

7.36 Page 5 2. Extra buzzer port



There is one buzz on the main board, but if the sound is too small, we can add a buzz outside, connecting to the output port for extra buzz.

7.37 Page 5 3. X,Y moving mode



If X,Y move directions are opposite of the key when move the workbench by manual, we can set these parameters below:


Left, front:  coordinate reduce,  coordinate increase.  coordinate reduce,  coordinate increase.

coordinate increase.

Right, back:  coordinate reduce,  coordinate increase.  coordinate reduce,  coordinate increase.

coordinate increase.

7.38 Page 5 4. Auto check port set



Auto check port set

front and back(X) correlation sensor(1-16): 0

left and right(Y) correlation sensor(1-16): 0

type 1.normal close 2.normal open select: 2

installation 1.Y1 axis 2.Y2 axis select: 1

X,Y check position 1.same 2.different select 1

Set needle sensor automatically: Can not only in a position at the same time to search for X,Y detection. But also X,Y were detected at different locations.

7.39 Page 5 5. Initialization

Initialize the parameters of system, all the parameters will revert to initialization settings after initialized. Before this operation, please remember all port settings, parameters of screwdriver, some import parameters, etc. After initialization, set them one by one.

7.40 Page 5 6. Chinese-English shift

This function mainly to switch the display between Chinese and English.

Appendix 1

Method for setting the use time limit

Use the time limit setting method is no longer a password, but the way to use the authorization. We can achieve any change in the use of the period, the use of the time limit is the way to use the date, not the number of days.

To set or modify the restriction of the use of date, as long as input the 16 bit number, which in front of the 8-bit said year, month, day (YYYYMMDD). Low 8 bit is to verify the legitimacy of eight former date character verification code, encryption using XOR mode. The following is the use of the method:

1. Set or modify the password in Menu 4-1-5.

This 8-bit password used for achieving the XOR algorithm or modifying system time after setting the use limit.

(Because the use of the time limit is based on the system time to judge, so set the use of restrictions on the clock can't be arbitrarily modified, Once you have set the use of restrictions, the machine will be locked if customer destroy the clock power or chip)

2. Set use time limit in Menu 4-1-7.

Enter the 16bit setting characters, the former 8 are the use of the period of years, months, days. Latter 8 are used for verification code.


The generation of verification code is as follows:

Such as the password of the machine is 12345678, to authorize the machine to use in August 11, 2013, then the verification code of manufacture if 20130811 XOR 1234578 equals 26167989, then get the legal authorization code 2013081126167989, This license code allows the machine to be used to the machine clock in August 11, 2013. We can continue to authorize delay when expired. If you want to unlock the permanent use of a time, then use a legal authorization code with "3" at the first character of time to unlock.

Note:

Use method of XOR:

1. Use computer to open the calculator.
2. Select view/science mode.

3. 20130811  12345678 then got the result 26167989.